



RED ANGEL

A/C Stop Leak | #49496

Red Angel A/C Stop Leak repairs common leak points in automotive A/C systems. Activated at the leak point only, Red Angel will not crystallize with existing oxygen or moisture in the system. After repair is achieved, Red Angel will continue to lubricate and condition working parts. Use Red Angel to fix A/C leaks, for preventative maintenance, or to warranty hard part replacement against future leak points.

- Remarkable ability to repair and seal leaks in condensers, evaporators, connection hoses, gaskets, and O-rings
- Contains no solid or particulate matter that will clog the A/C system, or harm a recovery unit
- Forms a chemical weld sealing leaks in both R-12 or R-134a systems
- Safe to use and best of all — it's a permanent seal



2014 bluedevil products | all rights reserved

Directions

follow us on:   

1. Locate the A/C low side service port.
2. Start Engine and turn A/C to maximum cooling.
3. Fill A/C oil injector with 2 oz. of Red Angel A/C Stop Leak and connect to the low side service port while you recharge the system with the appropriate amount of refrigerant.
4. Allow A/C system to run for 15 minutes to circulate Red Angel and seal all leaks.

Not recommended for systems that cannot hold 5 inches of vacuum for 25 minutes or 15 inches of vacuum for 5 minutes. Also not recommended for systems that lose more than 1 pound of refrigerant per day or leaking compressors. Not for use in electrically driven compressor systems.

CAUTION: AVOID CONTACT WITH SKIN. KEEP OUT OF REACH OF CHILDREN. ALWAYS USE PROTECTIVE EYEWEAR.

DISPOSAL: In accordance with all local, state and federal regulations.

For additional information regarding the installation of this product or any other general questions, please visit www.gobluedevil.com or call our support line at **1.888.863.0426**